

AIRDECK

SOFT LANDING SYSTEM

IMPORTANT INFORMATION

Please contact Airdeck Safety for advice on integrating the use of these products into your RAMS. Please ensure you have completed your warranty application.

In the event of a personnel or materials fall or impact the AirDeck inner liner should be replaced.

WARNING: AirDeck Original must be used in constraint i.e with boundary walls or support. Avoid contact with flames or other ignition sources.

- Please refer to product assembly Instructions.
- AirDeck Safety is suitable for working heights of 2.5m or less from the top of the product and below.
- Please ensure inflation levels are maintained as specified. This is critical for safe deployment. Under or over inflation risks injury.
- The proprietary InflatorDeck Nozzle and authorised appliance must be used.
- When not in use please store in a dry location and out of direct sunlight
- Liners should be inspected annually for any signs of abrasion or deterioration. Please complete the below with an indelible marker:

1. _____ / _____ / _____

2. _____ / _____ / _____

3. _____ / _____ / _____

4. _____ / _____ / _____

5. _____ / _____ / _____