



IMPORTANT INFORMATION

Please contact Airdeck Safety for advice on integrating the use of these products into your RAMS. Please ensure you have completed your warranty application.

In the event of a personnel or materials fall or impact the AirDeck inner liner should be replaced.

WARNING: AirDeck Original must be used in constraint i.e with boundary walls or support. Avoid contact with flames or other ignition sources.

- Please refer to product assembly Instructions available at airdecksafety.com
- AirDeck Safety is suitable for working heights of 2.5m or less from the top of the product and below.
- Please ensure inflation levels are maintained as specified. This is critical for safe deployment. Under or over inflation risks injury.
- The proprietary InflatorDeck Nozzle and authorised appliance must be used.
- When not in use please store in a dry location and out of direct sunlight
- Liners should be inspected annually for any signs of abrasion or deterioration. Please complete the below with an indelible marker:

1. _____ / _____ / _____

2. _____ / _____ / _____

3. _____ / _____ / _____

4. _____ / _____ / _____

5. _____ / _____ / _____